

Zetta Z15-ZA8 motion triggered digital video recorder

Overview

Z15-ZA8 is a long standby time motion triggered DVR that is covert and can standby for 2 weeks. The ZA8 motion detector is connected to the Z15 with an USB cable. Z15 is set to Car-Activate and Car-Stop Recording and the slide switch is put to custom mode. Operated by internal battery, the DVR will record as long as motion is detected, and will keep recording for 30 seconds after motion stops.

Feature

Adapt to lighting condition – select outdoors / 50Hz / 60Hz to adapt to the lighting condition

Sensitivity – select the motion trigger sensitivity, high / medium / low

Package Content

Please unpack your motion detector and check that the following are included:

Zetta Z15-ZA8 DVR

This quick start guide

1. Charging

The DVR comes with an internal rechargeable battery. To use the DVR for the first time or not using it for a long time, please fully charge the battery for at least 8 hours. You can charge your DVR through the USB port of your computer, a 5V 1A output DC adapter or 5V 1A output power bank.

2. Updating time

To update the time on Z15, disconnect the USB cable from ZA8 to Z15 and use the bundled USB cable to connect the Z15 to your computer. Then use the Zetta Widget to update the time. For details on how to use the Zetta Widget, please see www.zetta.com.hk - support - knowledge base - how to change time and setting. Then connect the ZA8 USB out to the Z15 USB port again and turn on ZA8.

3. Operation

The power button is located at the top side of ZA8. It can turn on or off ZA8.

Start detection

Press and hold the Power button for approximately 4 seconds, then release the button. The green LED will then be steady on and flashes for 30 more seconds, and then off. It is in motion triggering mode now.

If the green LED is not on after you have release the button for over 10 seconds, please connect the detector to a power bank or DC adapter, or use a pin to press the RESET button to reset the detector.

Stop detection


Press and hold the Power button until the yellow LED is on and then off (for approximately 10 seconds).

Technical Support

Before contacting us, please visit the "Support" section in <http://www.zetta.com.hk>. For further question on feature and usage, please email us at support@zetta.com.hk

www.zetta.com.hk

Zetta ZA8 at a Glance



Status

With DC adapter or power bank connected

Yellow LED on: charging

Yellow LED off: charging complete

Power on

Green LED will flash for 30 seconds to indicate the motion detector is on. Then the green LED will be off.

Option

Please use a slotted screwdriver to open the bottom casing and set the jumper as follows for your environment. The bottom casing is locked by buckle so please slide the slotted screwdriver inside the casing and push it out. Please ONLY open from the USB side.

